



CHANGING A.C.M. BLADES

Hold the knife handle with the blade pointing away from yourself.



Twist the knurled collar clockwise to loosen the handle and pull out the old blade.



Insert new blade and turn collar anti-clockwise to tighten.

